
FASTUS
Good Thinking, Good Future

INSTRUCTION MANUAL

IO-Link Hub, Temperature RTD 8-input

UR-DS8RTD



IO-Link

OPTEX FA CO., LTD.

Thank you for purchasing the UR-DS8RTD IO-Link Hub.

This manual includes the information required to use the UR-DS8RTD. Please read this manual carefully before use, and fully understand the functions and performance before using this product correctly. Also, keep this manual in a safe place after reading it, and always keep it handy.

Safety Precautions

Safety precautions for ensuring safe operation of this product are displayed as follows with the following symbols.

Precautions listed here describe important information about safety. Make sure to follow them accordingly.

Safety Symbols

⚠WARNING	Indicates that any improper operation or handling may result in moderate or minor injury, and in rare cases, serious injury or death. Also indicates a risk of serious property damage.
⚠CAUTION	Indicates that any improper operation or handling may result in minor injury or property damage.


⚠WARNING	
	Do not disassemble, repair, modify, deform under pressure or attempt to incinerate this product. Doing so may cause injury or fire.
	Do not use this product in water or in a location where it may be exposed to water. Do not use this product if wet. Doing so may cause a fire or damage the product.
	This product is not explosion-proof and should not be used around flammable or explosive gases or liquids. Doing so may cause ignition resulting in an explosion or fire.
	Do not use air dusters or any spray that uses flammable gas around the product or on the inside of the product. Doing so may cause ignition resulting in an explosion or fire.
	Do not use this product in environments other than industrial environments. If used in other environments, it may cause induction and radiation interference.
	Do not install this product or its cables in any of the following locations. Doing so may cause a fire, damage or a malfunction. 1. Locations where dust, salt, iron powders or vapor (steam) is present. 2. Locations subjected to corrosive gases or flammable gases. 3. Locations where water, oil or chemical splashes may occur. 4. Locations where heavy vibrations or impacts may occur. 5. Locations where the ambient temperature exceeds the rated range. 6. Locations subject to rapid temperature changes (or where condensation occurs). 7. Locations with strong electric or magnetic fields. 8. Outdoor locations or locations subject to direct light.
	Do not use the product at voltages or with AC power supplies that exceed the rated voltage. Doing so may cause a fire or damage the product.
	What to do in the event of a malfunction such as smoke being emitted from the product: If you detect any malfunction including emission of smoke, abnormal smells or sounds or the body becoming very hot, immediately stop operating the product and turn off the power. Failure to do so can cause fire. Repairing the product is dangerous and should in no way be performed by the customer. Contact an OPTEX FA sales representative for repairs.
	What to do if water enters the product: If water or any other liquid enters the product or the cable, immediately stop operating the product and turn off the power. Using the product in this condition may cause a fire.

⚠CAUTION	
	Do not touch this product or the cable with wet hands. Incorrect wiring can cause product failure or malfunction.
	When wiring this product, do so properly according to this manual and specified instruction manuals. Incorrect wiring can cause product failure or malfunction.
	Connect only specified cables to this product. Use of cables other than those specified can cause malfunction.
	Keep wiring separate from high voltage and motor circuits. Using the same wiring can cause malfunction or failure. If this is unavoidable, shield with a conductor such as an earthed conduit.
	Install this product as far away as possible from high-voltage equipment, equipment that generates large switching surges and equipment that generates noise, such as welding machines or inverter motors.
	Use this product with the end plate (sold separately) mounted to the DIN rail. Make sure locking mechanisms are locked before use.
	Tighten the mounting screws that attach the power terminal block to the main unit with a torque value of 0.25 N•m or less.
	Do not apply torsional stress to cables. Doing so can cause cables and connectors to malfunction. Secure the communications cable drawn out of this product within lengths of 30 cm to ensure no load is applied to the product.
	Do not drop this product or subject it to strong impact or vibrations. Doing so can cause malfunction.
	This product generates heat during operation, so do not maintain physical contact for long periods of time. Doing so can cause low-temperature burns, etc.
	Use this product within the rated range.
	Do not cut power during communication.
	Make sure to turn OFF the power before connecting or disconnecting cables and connectors. Connection or disconnection while running can cause malfunction.
	Always hold the connector when connecting or disconnecting cables and do not apply excessive force to cables.
	When removing a connector, do not touch the terminals inside the connector or allow foreign objects to get inside.
	When using power cables or commercially available switching regulators, make sure the frame ground (FG) is grounded.
	Wait until after transient state (approx. 2 sec.) when power is turned ON before use.
	Make sure to use an isolation transformer for DC power supply.
	If a surge occurs in the power supply used, use a surge absorber for the source of generation.
	If this product used in a manner not specified by the manufacturer, the protection provided by this product may be impaired.


1. Overview

The IO-Link Hub UR-DS8RTD is a remote unit for reading up to 8 platinum resistance thermometers that measure the temperature of various objects with process input data from the IO-Link master.

2. Included Items



- UR-DS8RTD unit




- This instruction manual

* If the terminal block is lost or damaged, order the following model.
- Platinum resistance thermometer input terminal block (resistance thermometer input terminal block): UR-FD16A (1 piece)
- Power supply terminal block: UR-FP7T

3. Dimensions


Unit (mm)



4. Installation


Follow the steps below to install this product.

1. Hook the upper hook on the back of the product to the DIN rail.
2. Push the lower side from the front.
3. Push the DIN rail mounting hook up to lock the product in place.



Install this product at least 10 mm away from an adjacent device and structure.

5. System Configuration



6. Connection


When inserting or removing wires from the terminal block, press the open/close key (orange part) while inserting/removing.

In the case of ferrules, they can be inserted without pressing the open/close key, but when pulling them out, press it in while doing so. Pulling out without pressing in the key may damage the terminal block.

For the crimping tool, use CRIMPFOX6 from PHOENIX CONTACT. Crimping or inserting with other tools may result in a loss of measurement accuracy or damage to the terminal block when pulled out.

Wiring to the platinum resistance thermometer input terminal block

Connect the platinum resistance thermometer to the 16-pole platinum resistance thermometer input terminal blocks.




Applicable wire size: AWG 24 to 18

Ferrule: PHOENIX CONTACT

Model: AIxx-10yy (xx: Maximum wire diameter, yy: Color No.)

Please refer to the user's manual for the combination of wire sizes and ferrule models.



When inserting the ferrule into the terminal block, the flat side of the crimp should face the open/close key as shown in the illustration on the right. Inserting the ferrule in a different direction may result in incorrect measurement.

Excessive insertion or removal of the ferrule or platinum resistance thermometer input terminal block may cause a change in contact resistance, which may degrade measurement accuracy.


In this case, replace the ferrule of the connected platinum resistance thermometer and the platinum resistance thermometer terminal block.

*For replacement platinum resistance thermometer terminal blocks, see **2. Included items**.

Wiring to the IO-Link master

Connect the IO-Link master to either the e-CON socket on this product or the IO-Link communication terminals on the power terminal block.

- **Connecting to the IO-Link communication terminals on the power terminal block**



Note 1: 0V, 24V and C/Q is connected internally with the IO-Link communication e-CON socket.

Applicable wire size: AWG 24 to 12


A ferrule, single or stranded wires can be used.

Stripped wire length: 10 mm


Ferrule: Typical model; AI0.5-10WH (AWG20) from PHOENIX CONTACT

Please refer to the user's manual for the combination of wire sizes other than AWG20 and ferrule models.

- **Connecting to the IO-Link communication e-CON socket**



7. Part Names



No.	Name	Function
(1)	POWER LED (green)	Turns on when the unit power is turned on.
(2)	COM LED (green)	Illuminated: After startup, before IO-Link communication is established 1 second on 0.1 second off: IO-Link communication established 0.55 second on 0.55 second off: Find me 0.1 second on 0.1 second off: IO-Link communication cutoff
(3)	ERROR LED (Red)	Turns on when IO-Link communication stops or some other error occurs.
(4)	Input type LED (orange)	"✓" is lit if a resistance thermometer is connected to each channel. It lights up if the process input data range is in units of 0.1°C.
(5)	Platinum resistance thermometers input terminal block (Channel 0 to 3)	Connect platinum resistance thermometers for channels 0 to 3.
(6)	Platinum resistance thermometers input terminal block (Channel 4 to 7)	Connect platinum resistance thermometers for channels 4 to 7.
(7)	Power terminal block (0 V, +24 V)	Supplies unit power (+24 V, 0 V) This seven-pole removable connector has a pitch of 5.08 mm and a rating of 12 A. It uses AWG 24 to 12 wires. Unit power (+24 V, 0 V) and C/Q are connected internally with the terminals of the e-CON socket, and either the power terminal block or e-CON socket can be connected to the IO-Link master.
(8)	e-CON socket (4-pole)	Unit power (+24 V, 0 V) and C/Q can be wired to the IO-Link master via the e-CON socket.
(9)	DIN rail mounting hook	Slides for attaching/removing the product to/from the DIN rail.

8. Specifications

General Specifications

Item		Specifications
Power supply voltage		24 VDC +/-15% *1
Current consumption (at 24 VDC)		75 mA max. (If the IO-Link master is Field Prime compatible, the current is 95 mA max.)
Operating temperature		0 to +55°C (no freezing)
Operating humidity		5 to 95% RH (no condensation)
Storage temperature		-25 to +75°C (no freezing)
Storage humidity		5 to 95% RH (no condensation)
Vibration resistance		IEC 61131-2 compliant
Shock resistance		IEC 61131-2 compliant
Atmosphere		No corrosive gas
Operating altitude		0 to 2000 m
Installation location		In door use
Degree of protection		IP20
Measurement category		II
Pollution degree		2
Applicable regulations	EMC	EMC Directive (2014/30/EU), UK EMC (Electromagnetic Compatibility Regulations 2016)
	Environment	RoHS Directive (2011/65/EU), China RoHS (MIIT Order No. 32) UK RoHS (The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012)
Applicable standard		EN 61131-2
Compatible DIN rail		TH35-7.5Fe, TH35-7.5Al
Cable length		Maximum 20 m (between IO-Link master and IO-Link Hub) (If the IO-Link master is Field Prime compatible, the maximum length is 100 m)
Compatible wire		Power terminal block: AWG 24 to 12 Platinum resistance thermometer input terminal block: AWG 24 to 18
Material		Unit: PC; DIN rail mounting hook: POM; Terminal block: PA
Weight		Approx. 115 g (including terminal blocks, when not wired)
Included accessories		Instruction manual (this document),

*1 Use a Class 2 power supply or a power supply compliant with SELV (Safety Extra-Low Voltage) circuit and LIM (Limited Energy Circuit) circuit standards.


IO-Link Specifications

Item	Specifications
Host communication interface	IO-Link (operates as device)
Process input data byte count	16 bytes
Process output data byte count	1 byte
Minimum cycle time	1.2 ms
IO-Link revision	1.13
Communication speed	COM3 (230.4 kbps)/ COM2 (38.4 kbps) Switching by service data. (Default value: COM3)
Communication function operation power supply	IO-Link power supply

Input specifications of platinum resistance thermometer

Item	Specifications
Number of Input channels	8 channels
Compatible resistance thermometer	Pt100, 3-wire type
Maximum input current	Approx. 1 mA (When measured at 25 °C)
Measurement range	-200 to +1000 °C
Accuracy	-200 to -60 °C: ± 1.0 °C -60 to +300 °C: ± 0.3 °C +300 to +600 °C: ± 1.0 °C +600 to +1000 °C:± 2.0 °C (at ambient temperature of 25 °C)
Temperature characteristics	± 50 ppm/°C. (Within the ambient temperature range)
Resolution	16 bits
Dielectric withstand voltage	500 VAC for one minuter between platinum resistance thermometer input terminal batch and IO-Link batch.
Insulation resistance	10 Mega ohm between all I/O terminals and IO-Link terminals at 500 VDC
Inter-channel isolation	None (common)
Insulation method	Photocoupler, transformer insulation
Sampling cycle	2 ms

9. Circuit Diagram



10. Process Data

The process data exchanged by the product with the IO-Link master using IO-Link cyclic communication is as follows. IO-Link process data is transferred in big endian format. The table below is also in big endian format. The IO-Link master UR series from OPTEX FA transfers IO-Link process data converted into little endian format to the host network by default, so the byte order will be the reverse of that in the table below.

Process data	Byte	bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
Process input data *1	+0	Channel 7 temperature upper byte							
	+1	Channel 7 temperature lower byte							
	+2	Channel 6 temperature upper byte							
	+3	Channel 6 temperature lower byte							
	+4	Channel 5 temperature upper byte							
	+5	Channel 5 temperature lower byte							
	+6	Channel 4 temperature upper byte							
	+7	Channel 4 temperature lower byte							
	+8	Channel 3 temperature upper byte							
	+9	Channel 3 temperature lower byte							
	+10	Channel 2 temperature upper byte							
	+11	Channel 2 temperature lower byte							
	+12	Channel 1 temperature upper byte							
	+13	Channel 1 temperature lower byte							
	+14	Channel 0 temperature upper byte							
	+15	Channel 0 temperature lower byte							
Process output data	+0 *2	Channel 7	Channel 6	Channel 5	Channel 4	Channel 3	Channel 2	Channel 1	Channel 0
		Input range 0: up to 327.67°C, 1: up to 1000.0 °C							

*1 When the platinum resistance thermometer is not connected, the temperature data is 32767 (0x7FFF).

*2 When index number 74 ("Input range switching") of the service data is "0", this designation by process output data is valid. In case of "1", the value is fixed in 0.01°C increments, and in case of "2", the value is fixed in 0.1°C increments.

11. Service Data

The service data for this product that can be read and written via IO-Link ISDU handling is as follows.

Name	Index number	Subindex number	Read/ Write *1	Backup Subject	Data byte count	Default value	Setup value	Setting Details
System command	2	0	W		1	-	130	Initialization of setting value
							131	Stops IO-Link communication after reverting setting values to default values (Back-to-Box)
Device lock	12	0	R/W	✓	2	0	0	Unlocks the storage function.
							2	Storage function lock.
Tag name	24	0	R/W	✓	32	*2	-	Can be used to set a name for this unit, such as the device function or installation location.
Input range switching	74	0	R/W	✓	8	0	-	Switches the input range for channels 0 to 7. The first byte is the value of channel 0. For the meaning of each byte value, refer to the setup value of subindex numbers 1 to 8.
		1 to 8		✓	1		0	The input type is switched using process output data.
							1	Measures up to 327.67°C in 0.01°C increments.
							2	Measures up to 1000°C in 0.1°C increments.
Averaging time	79	0	R/W	✓	8	5	-	Sets the averaging time for channels 0 to 7. This time is the time required to follow up to 90% of the step variation in the measured value. In twice in this time, it follows up to 99%.
		1 to 8		✓	1		0	20 ms
							1	40 ms
							2	80 ms
							3	160 ms
							4	320 ms
							5	640 ms
							6	1.23 s
							7	2.5 s
							8	5 s
							9	10 s
Internal temperature	161	0	R		2		-2739 to 10461	Returns the temperature on the internal board. The unit is 0.1°C.
Operating time	162	0	R		4		0 to 4294967295	Returns the internal operation time. The unit is 7.5 minutes.
Display unit character string	194	0	R/W	✓	1	0	0	Outputs temperature in degrees Celsius.
							1	Outputs temperature in degrees Fahrenheit.
Device identification request (Find me)	204	0	R/W		1	-	0	Disable the function of device identification requests.
							1	Enable the function of device identification requests. The COM LED flashes at 0.55 sec. intervals.
Communication speed switching	225	0	R/W	✓	1	0	0	COM 3
							1	COM 2

*1 R: Read only, W: Write only, R/W: Read/Write

2 The default value is 32 ""(asterisk) characters

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

*This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

- About Field Prime

Field Prime

This device, as well as any equipment bearing this logo, is compatible with Field Prime. For more details about Field Prime, please refer to our website.

- Support for the China RoHS directive

For details on the support for the China RoHS (the Administrative Measure on the Control of Pollution Caused by Electronic Information Products), see the following website.
https://www.optex-fa.com/rohs_cn/

OPTEX FA CO., LTD.

[Headquarters]
91 Chudoji-awata-cho, Shimogyo-ku, Kyoto 600-8815 JAPAN
TEL +81-75-325-1314 FAX +81-75-325-2936

https://www.optex-fa.com