

EMO-420 Digital Output Module



Code	: EMO-420 Digital output module
Function	: Digital output
Output rating	: max. 40 mA @ 18 V ---
Dielectric strength	: From device supply to module output _2kV ~ From device ground to module output _500V ~
Insulation resistance	: From device supply to module output _>999,9MOhm From device ground to module output _>999,9MOhm
Overall size of the equipment	: 14mm x 30,7mm x 41,4mm
Applicable products	: ESM-4450, ESM-4950, ESM-9450, ESM-4400, ESM-4900,
Module labels	EZM-4450, EZM-4950

PACK LIST

Please visual check

- 1 piece of EMO-420 Digital output module
- 1 piece of EMO-420 module presenting label


 Before the module installation you must read instruction manual of which applicable product.





Thank you very much for buying EMKO`s product.





Installing and Pulling Out Input/Output Modules


 First, detach all cable connections from the controller and uninstall it from the panel.


 Suppress to the lock pins where top and bottom of the controller.


 Pull the cover case with your other hand from front panel to rear side.



 Pull out the cover case from the controller

 Slide input/output modules into socket.
Pull out the module from it's socket, instead of this module install the new one or other module user wants to use.

 Replace the cover case by taking care of the terminal numbers should be at right orientation.

 After adding or changing modules to the unit, these changes must be taken into consideration while mounting of the unit to the system. If mounting is incorrect, it can cause accidents to harm system, operator or person who does the mounting. Responsibility of these kind of harmful events belongs to the user.

 After the module installed to the device succesfully, please stick on module presenting label where to participate in the module packet, to suitable module presenting box where on the device label.



Module presenting label

